

UV Cure Adhesive Applicator and Bar Code Scanner


The optional barcode scanner can select and manage all dispense paths, speeds, settings etc directly from a work order, pallet or any label.

The scanner reads dozens of industry standard bar codes and is seamlessly integrated with the robot. It may be added in the field with no modifications required.

The user may select the machine to either load a job from the included Compact Flash card or to begin the dispensing cycle with the bar code scanner.



The Popular RP-1215 Robot



Advanced Step & Repeat Mode

Software features "cloning" For automatically dispensing in row and column arrays.

