



Application Bulletin

3809



RD 2500 Large Format Fluid Dispenser

The most flexible dispensing table available. It combines a smart work bench to a built in precision overhead servo XYZ gantry system.

Mechanism are neatly tucked in and do not add to the width of the bench. This provides easy access from front, sides, and top requiring less operator "reach" to the center of the table.

**Shown: RD 2500 Robotic Dispenser
50"x 100" Travel**

Many Unique Design Features

The T Slot table base with 25 Full length slots provides more than ample fixturing possibilities for most applications.

Under this table surface, the actual machine base is fabricated from heavy steel tubing, then is ground to a specified flatness.

This modular design provides the ideal foundation for mounting virtually any type of top surface including:

- T Slot Table
- Vacuum Table
- Panel Conveyor
- Custom Plates

Standard machine can travel at over 32 inches per second and is available in the following travels:
100" x 50" (2500mm x 1250mm)
50" x 50" (1250mm x 1250mm)

We offer limitless customizing capabilities for other sizes.

